

Vernier Photogate

(Order Code VPG-BTD)



This general-purpose photogate can be used for a wide variety of experiments in physics and physical science classes. Examples include

- measuring freefall acceleration.
- studying the swing of a pendulum.
- measuring the speed of a rolling object.
- timing the period of a rotating object.
- measuring the speed of objects undergoing collisions.

The Vernier Photogate can be used as a traditional photogate for objects traveling between the arms of the gate, and also as a laser gate for objects passing outside of the arms of the gate. A mechanical shutter is used to block the internal gate, switching the device to laser gate mode. The laser gate mode requires a visible pen laser (not supplied). You can expect good results with a typical Class IIIa type laser pointer, with a power of less than 5 mW.

The Vernier Photogate can be connected directly to an interface, or in a daisy-chain configuration. In the daisy-chain mode, up to four photogates can be connected to a single channel of the interface by connecting one photogate to another photogate, connecting the last one directly to the interface.

The Photogate is designed for use with the following interfaces:

- Vernier LabPro[®] (for use with computers, TI graphing calculators, or Palm Powered[™] handhelds) (BTD version)
- Texas Instruments CBL 2[™] (BTD version)
- Universal Lab Interface (ULI) (DG version)

Note: This product is to be used for educational purposes only. It is not appropriate for industrial, medical, research, or commercial applications.

What is Included with the Photogate?

The Vernier Photogate includes a cable for connection to one of the interfaces listed above. An accessory rod is included for attachment to a ring stand.

Internal Gate Mode and Laser Gate Mode

The Vernier Photogate operates in two modes. A shutter over the internal gate detector determines the operating mode. The shutter is on the inside of the thinner gate arm. Open the shutter to use the internal gate, and close the shutter to use the external laser gate. A red LED is on when the gate is blocked in either mode.

To use the internal gate mode, open the shutter and position the photogate. When the gate is blocked the red LED will be illuminated.

To use the external laser gate mode, close the shutter for the internal gate. The laser port is on the outside edge of the gate adjacent to the captive bolt. Align your laser so the beam enters the port and turns off the LED. Blocking the laser beam at any point in its path will then turn the LED back on. The path of the laser need not be a straight line. You may want to use mirrors to create a complex path that is crossed by the moving object multiple times.

Laser Safety Note: Do not align the external laser gate by sighting by eye. Follow all safety precautions indicated by the laser manufacturer.

Daisy-Chain Mode

The Vernier Photogate can be connected in a daisy-chain mode. Connect one gate to the interface, and then connect the next gate to the first Vernier Photogate using the white BTD socket on the arm of the photogate. Up to four Vernier Photogates may be connected to a LabPro interface at one time. The daisy-chain mode requires the cable from the VPG-BTD model. If you have purchased the VPG-DG version for compatibility with your interface, you will need to purchase an additional cable to make each photogate-to-photogate connection. (order code PG-BTD)



In the daisy-chain mode the analyzing software has no way to determine *which* gate has been blocked, so be sure that this information is not needed. One common setup is to use gate timing, so that the software reports the time a gate is blocked. If you know the order in which gates are blocked from the geometry of the experiment, then daisy mode will work.

Note that in a typical collision experiment where two objects are passing through the

two gates, the gates may have overlapping block intervals. In this case, you must connect the gates to two separate channels on the interface. Motion timing mode can be used if the daisy-chained gates are equally spaced. Enter the distance between gates in your software to determine position, velocity, and acceleration of a single object passing through a series of photogates.

This sensor is equipped with circuitry that supports auto-ID. When used with LabPro, the data-collection software can identify the sensor and uses pre-defined parameters to configure an experiment appropriate to the recognized sensor. The auto-ID feature is not supported when using calculators, computer software older than Logger *Pro* 3, or LabPro OS older than 6.26.

Use of the Vernier Photogate with a Computer

This sensor can be used with either a Vernier LabPro or a Universal Lab Interface.

1. Connect the photogate or photogates to the appropriate port or ports on the interface.
 - LabPro—Connect the VPG-BTD photogate to DIG/SONIC 1 on the interface. A second VPG-BTD photogate can be connected to DIG/SONIC 2, or additional VPG-BTDs can be attached in daisy-chain mode.
 - ULI—Connect the VPG-DG photogate to DIG 1 on the ULI II. A second VPG-DG photogate can be connected to DIG 2. The VPG-DG can also be used with the original ULI with the proper adapter (order code ADP, \$5). Additional VPG-BTDs can be attached in daisy-chain mode.
2. Start the data-collection software on the computer. If you are using a Macintosh or Windows[®] computer, run the Logger *Pro*[®] or Logger Lite[®] software. If you are using an older Macintosh computer, run the ULI Timer program.
3. Open an experiment file in the Logger *Pro* or ULI Timer folder, and you are ready to collect data.

Using the Vernier Photogate with a TI Graphing Calculator

This sensor can be used with a TI graphing calculator and any of the following lab interfaces: LabPro or CBL 2. Here is the general procedure to follow when using the Vernier Photogate with a graphing calculator:

1. Connect the data-collection interface to the graphing calculator.
2. Connect the Vernier Photogate to any of the DIG/SONIC ports on the interface.
3. Start the EasyData or DataMate App—the application you choose to use depends on your calculator and interface.
4. The Vernier Photogate will be identified automatically, and you are ready to collect data.

If the data-collection application is not on your calculator, use the following instructions to load it onto the calculator.

- **EasyData App**—This program may already be installed on your calculator. Check to see that it is EasyData version 2.0 or newer. If it is not installed or is an older version, it can be downloaded to your computer from the Vernier web site, www.vernier.com/easy/easydata.html. It can then be transferred from the computer to the calculator using TI-Connect and a TI unit-to-computer cable or TI-GRAPH LINK cable. See the Vernier web site, www.vernier.com/calc/software/index.html for more information on the App and Program Transfer Guidebook.
- **DataMate program**—This program can be transferred directly from LabPro or CBL 2 to the TI graphing calculator. Use the calculator-to-calculator link cable to connect the two devices. Put the calculator into Receive mode, and then press the Transfer button on the interface.

Use of the Photogate with Palm Powered Handhelds

This sensor can be used with a Palm Powered handheld and the LabPro.

1. Connect the Palm Powered handheld, LabPro, and the Photogate.
2. Start Data Pro, version 1.2 or newer.
3. Tap New, or choose New from the Data Pro menu. Tap New again. The Photogate will be identified automatically.*
4. You are now ready to collect data.

Mounting the Photogate

Connect the clear phone plug from the cable assembly into the modular phone jack on the photogate housing. Plug the other end of the cable assembly into the lab interface or adapter cable. Test the operation of the photogate by watching the LED when the beam is blocked. The LED will go on when the photogate is blocked. The rod included with the photogate can be threaded into the hole in the photogate end to provide a convenient way of mounting the photogate. The rod can be mounted to a ring stand using standard laboratory clamps. Clamp the photogate to a support rod or mounting bracket. For internal gate mode, position the photogate so the object to be timed will pass through the photogate, blocking the beam. For external laser gate mode, it is easier to roughly align the laser, and then position the photogate so the LED goes out.

* LabPros with OS earlier than 6.26 will not auto-ID the Vernier Photogate. If your sensor does not auto-ID, tap Setup and set up an experiment. See www.vernier.com/calc/flash.html for information on updating your LabPro OS.

Photogate Specifications

Power requirements: 5 VDC at 40 mA

Infrared source: Peak at 880 nm

Output is low and LED off for unblocked gate

Output is high and LED on for blocked gate

How the Photogate Works

The Vernier Photogate contains two different light detectors. In internal gate mode, a narrow infrared beam is directed to a fast IR detector, which provides very accurate signals for timing. In external laser gate mode, a fast visible light detector located at the end of a tube responds to the presence of a low-power laser beam.

Add a Low-Friction Pulley

The Ultra Pulley Accessory (order code SPA) connects to the photogate by using the accessory rod that comes with the photogate. Place the rod through the hole in the photogate and move the pulley into position so that the rod can be threaded into it.

Tighten up the rod so that the pulley is held firmly against the photogate. The Ultra Pulley is a low-friction pulley with ten spokes. The spokes break the photogate beam so that the rotation of the pulley can be monitored by the photogate. For example, the motion of an Atwood's machine could be studied with an Ultra Pulley and the Vernier Photogate.



Laser Pointer Stand

This light-weight tripod is a perfect support for a laser pointer. The stand features fold-out legs and a clip attached to the adjustable ball. A socket head assembly securely holds the laser in place. This assembly allows you to accurately point the laser at the photogate. A VELCRO® strap integrated into one of the tripod legs allows you to attach the laser to objects such as ring stands and railings.

Vernier Photogate and Early TI Publications

The Vernier Photogate should not be used as a replacement for the simple photogates (using the TI light sensor) described in the *CBL Experiment Workbook* (which comes with the CBL) or in *Exploring Physics and Math with the CBL System*. The programs used with these books will not work with this type of photogate.

More Information on Geometric Aspects of Photogate Timing

Photogates have a number of geometric complications that result in the effective length of an object passing through the gate being slightly less than the actual length. For a good discussion of these issues, see Eugene P. Mosca and John P. Ertel, "Photogates: An instrument evaluation," *Am. J. Phys.* **57** (9), 840-844 (1989).

Experiments Using the Vernier Photogate

The Vernier Photogate is used in several experiments in the books *Physics with Calculators* and *Physics with Computers*, both published by Vernier Software & Technology. See these books for detailed experiments. Here are some brief examples of things you can do with a photogate.

1. If you know the diameter of a ball rolling through a photogate, you can determine the speed of the ball from the ratio of the diameter to the time the gate is blocked by the ball. This requires only one gate, but the gate has to be positioned carefully so the light beam intersects the middle of the ball.
2. Using two photogates positioned at a known separation, you can determine the speed of an object from the time interval between the breaking of the first beam to the breaking of the second. This mode is known as pulse timing.
3. Set up a pendulum so that the bob swings through the photogate. The time interval from one block to the third block yields the pendulum period.
4. Use the laser gate at floor level to measure the "hang time" of a jumper. The jumper's shoes will block the beam while on the floor. The time interval of interest is then the unblock to block time.
5. Use a super pulley to construct an Atwood's machine, consisting of two masses connected by a flexible string. The string passes over the pulley, causing it to rotate as the masses move. Use motion timing to measure the position, velocity, and acceleration as a function of time.
6. Measure the free fall acceleration of a picket fence using either the internal gate or the laser gate. Motion timing will give you the position, velocity, and acceleration as a function of time. Do the two modes give different results?

Warranty

Vernier warrants this product to be free from defects in materials and workmanship for a period of five years from the date of shipment to the customer. This warranty does not cover damage to the product caused by abuse or improper use.



Measure. Analyze. Learn.™

Vernier Software & Technology

13979 S.W. Millikan Way • Beaverton, OR 97005-2886

Toll Free (888) 837-6437 • (503) 277-2299 • FAX (503) 277-2440

info@vernier.com • www.vernier.com

Rev. 9/7/06

Logger *Pro*, Logger Lite, Vernier LabPro, Go!Link and other marks shown are our registered trademarks in the United States.

CBL 2 and CBL, TI-GRAPH LINK, and TI Connect are trademarks of Texas Instruments.

All other marks not owned by us that appear herein are the property of their respective owners, who may or may not be affiliated with, connected to, or sponsored by us.



Printed on recycled paper.